
Whirlpool

TOP AND CABINET PARTS

AUTOMATIC WASHER




TOP AND CABINET PARTS

IIIus. No.	Part No. [DESCRIPTION
1 2	357213	Nut, Push-In (2)
2	3949476	Top White Model
	3949476	
3	62750	
5		Cabinet
J	63424	
	63425	
6	62780	
		& Rear Panel (2)
7	3349654	Cabinet-Sound
		Damper
8	3356311	Screw & Washer,
4.4	0040007	Lid Switch (2)
11 13	3949237 3351355	Switch, Lid Screw, Lid Hinge
13	3331333	Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	54583	
17	19119	
18	21258	
		Hinge (2)
19		Lid
	3352718	White Model
	3352719	Almond Model
20	358684	
22	93770	· 1 · / · ()
28	384435	Screw, 10-16 x 1/2 (5)
31	90016	Clip, Harness
32	3362952	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Model: LSL9244EQ0, LSL9244EZ0 (Designer White) (Designer Almond)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	16123	Washer, Water Inlet Hose (4)	16		Cap, End (L.H.) White Model Almond Model	39		Panel, Console White Model Almond Model
2	694419	(1–1/16 x 5/8) Mini, Buzzer Hose, Water	18		Valve, Water Mixing	44		Knob, Timer White Model
3	3949368	Inlet (2) (Blue Coupler)	19		Screw, 10-24 x 3/8 (2)	45		Almond Model Dial, Timer
5	3949369	(Red Coupler) Hinge, Console (2)	21 22		Clamp, Hose Hose, Vacuum	40		White Model Almond Model
6 7	3357978 62747	Panel, Rear Pad, Rear Panel	23		Break Clamp, Hose	46		Knob, Controls White Model
8		Hose, Drain (4 ft.)	24 25		Break, Vacuum Support, Rear Panel	49		Almond Model Screw, 8–18 x 1.25 (Panel to Top)
	661577	(9 ft.)	26	3361809	Connector–Drain Hose.	50 51	62863	Screw, 10–16 x 3/8 Cap , End (R.H.)
	3357090	(Not Included) Extension Drain Hose	27 28		Clamp, Hose Hose, Pump To	0.		White Model Almond Model
		(21 Inches) (Not Included)	30		Drain, Connector Clamp, Hose	55	3357011	10-16 x 1/2
9	3951703		31 32		Clamp, Hose Hose, Pump To Tub	57		Nozzle, Hose Drain
		(Motor Not A Service Part)	34		(Includes #30) Switch, Clean	58		Clamp, Drain Hose
11 12	90767 3366847	Screw, 8A x 3/8 Switch, Water Level			Touch (8 Pads) White Model	59 60		Shield, Suds Harness, Wiring
13 14	3950194	Bracket, Control Cord, Power	36		Almond Model Screw, Timer Mounting			(Includes Power Cord) (For Detail See
15	3949468	(Power Cord Only Without Harnness) Strain Relief, Power Cord			(10–32 x 1) (2)			Page 9 & 10) Also See Clips

AGITATOR, BASKET AND TUB PARTS



881477 5

AGITATOR, BASKET AND TUB PARTS


Illus. No.	Part No.	DESCRIPTION
1	63580	-1
2	358237	Screw & Washer (5-16-24 x 1)
3	3363003	Clothes Mover
4	3347288	Agitator
5	63851	Tub Ring & Gasket
6	3359585	Seal, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3363663	Cam Driven
10	3366877	Dog, Agitator Clutch
11	3363661	Bearing-Driven
		Cam
12	21366	Nut, Spanner
13	3350649	Basket & Balance
		Ring
14	3361948	,
16	388893	Tub
		(Includes Item 25)
17	389140	Block, Basket
40	000707	Drive
18	383727	
19	3347780	
20	2046504	Switch
20	3946501	Agitator (Complete Asy.)
22	3350389	Spacer, Thrust
23	3347290	Cap, Barrier
20	3311200	(Includes #24)
24	3348855	Seal, Inner Cap
25	3948705	Hose, Bleach
26	3949550	Washer

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Model: LSL9244EQ0, LSL9244EZ0

(Designer White) (Designer Almond)

_ `	esigne	er willite) (Designer Allinc	maj		
	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	1	388952	Brake & Drive Tube (Complete) (Refer to Page 11	11	62611	Plate, Motor Mount To Gearcase
1	2	63292	For Further Breakdown) Washer, Spin	12 13	3364003	Grommet, Motor (4) Coupling, Motor & Isolation
2	3	62697	Tube Thrust Ring, Spin	15	3355454	Anti–Rattle
3			Tube Support	16	3357334	
	4		Ring, Retainer	17	3349637	Retainer, Motor (2)
4	5		Clutch (Complete)	18	3362089	Shield, Tub
5	6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)	19		To Motor Motor, Main Drive
7	7	62646	Cap, Clutch Spring (2)	20	62850	Switch, Main Drive Motor
	8	3951303	Spring, Clutch	21		Retainer, Pump (2)
	9		Gearcase	22	3363892	Pump (Complete)
16			(Complete)	23		Screw, 10–16 x 5/8
			(Refer To Page 12	24 25		Shield, Motor Screw,
[15]			For Further Breakdown	25	02003	10–16 x 3/8
	10	3357334	Screw, Gearcase To Base (3)	26 27		Capacitor Clamp, Capacitor
9 10 11/12 13 24			-16 17 25		20	18 19 21 22 21


MACHINE BASE PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: LSL9244EQ0, LSL9244EZ0 (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: LSL9244EQ0, LSL9244EZ0 (Designer White) (Designer Almond)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4	388498 3347812 3352501	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)
5 6		Clip, Harness Clip, Harness	14	3347243	Block, Disconnect	23		Connector, Etc
7		Retainer, (Suds Models)	15 16		(Use Term. 352088) Protector Connector	24	60687	Connector, Relay (Use Term.308569 Or 338664.)
8	352090	Timer, Block Disconnect (White)			(2-Way) (Use Term.94614)	25 26		E.T.C. Control Connector (T.P.A.)
9	352089	Timer, Block Disconnect (Black)	17	387566	Plug, Terminal (4–Way) (Power Cord) (Use M3 Screws)			(3-Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19		Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	27	3360056	Connector (T.P.A) (3–Circuit) (Pressure Switch) (Use Term.3948619 OR 3948620.)
11	353424	Or 94614.) Plug, Terminal (3–Way)	20	3347730	Receptacle (6–Way) (Use Term. 94613)	28	3354925	Block, Connector (Cold Valve) (Use Term.693217)
12	62505	(Power Cord) (Use Term.94613) Block, Disconnect	21	388818	Plug, Terminal (12–Way)	29	3354926	Block, Connector (Hot Valve)
12	02303	(Motor 2 Speed) (Use Term.352088)			(Use Term. 94613 Or 94614.)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619 OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2F

BRAKE AND DRIVE TUBE PARTS

For Model: LSL9244EQ0, LSL9244EZ0
(Designer White) (Designer Almond)




Part	DESCRIPTION
NO.	DESCRIPTION
388952	Brake And Drive Tube (Complete)
62658	Ring, Thrust
91939	Seal, Oil
356427	Seal, Drive Tube
356937	Spacer, Drive Tube
64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
64035	Ring, Retaining
	Shoe, Brake
62703	"T" Bearing,
62648	Spin Tube Cap, Brake Spring (2)
387806	Spring, Brake
62909	Sleeve, Brake Spring
63023	Cam, Brake Release
63022	Sleeve, Cam
64194	Driver, Brake Cam
90368	Ring, Retaining
	88952 62658 91939 356427 356937 64027 64035 64232 62703 62648 387806 62909 63023 63022 64194

FOLLOWING PARTS NOT ILLUSTRATED


Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin) 285208

GEARCASE PARTS



WATER SYSTEM PARTS

For Model: LSL9244EQ0, LSL9244EZ0 (Designer White) (Designer Almond)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6 7	65349 367031	Clamp, Hose Drain Protector (Not Included)

MISCELLANEOUS PARTS

For Model: LSL9244EQ0, LSL9244EZ0 (Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3976252	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose
4	3359452	(1–1/16 x 5/8) (4) Nut, Lock (3/8–16)
5	389102	Foot, Front (2)
7		Clamp, Hose

LITERATURE AND OPTIONAL PARTS

Illus. Part
No. No. DESCRIPTION

LITERATURE PARTS

LIT3950952 Installation, Instructions
LIT3366864 Guide, Use and Care
LIT3949009 Energy Guide
LIT3951704 Label, Wiring
Diagram

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT4313896 Manual, (Washer)

Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017 White 72107 Almond 72110 Golden Harvest

PAINT, PRESSURIZED SPRAY (13 oz.)

350938 Primer, Gray 350930 White 350956 Almond 261890 Golden Harvest

PAINT, BULK (1 qt.)

799344 White (Uncut) 978883 Almond (Uncut) 261891 Golden Harvest (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

SHIPPING KIT

3348675 Shipping Kit

ACCESSORY PARTS

89121 Stand-Pipe Kit 367031 Drain Protector 285320 Siphon Break Kit

881477